Holmes®

HABF27

1 TOUCH

BOX FAN



Owner's Guide

PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1) Read all instructions before using the appliance.
2) To avoid fire or shock hazard, plug the appliance directly into a 120 V AC electrical outlet.
3) Keep the cord out of heavy traffic areas. DO NOT let the cord hang over the edge of a table or counter. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiator, stoves, or heaters.
4) To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
5) Close supervision is necessary when any appliance is used by or near children, or by disabled people.
6) Always unplug the fan before moving it, putting on or taking off parts, cleaning, or whenever the fan is not is use. Be sure to pull by the plug and not the cord.
7) Avoid contact with moving parts. DO NOT operate without fan grills properly in place.
8) DO NOT operate any appliance with a damaged cord or plug, if motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical or mechanical adjustment, or repair.
9) DO NOT operate in the presence of explosive and/or flammable fumes.
10) Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by The Holmes Group may cause hazards.
11) DO NOT use outdoors.
12) Always use on a dry, level surface.
13) Keep unit away from heated surfaces and open flames.
14) WARNING: To reduce the risk of fire or electric shock, DO NOT use this fan with any solid-state speed control device.
15) DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.

WARNING: To reduce risk of electric shock and injury to persons, DO NOT use fan in window.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

ILLUSTRATION



A. Front Grill
B. Directional Grill
C. Directional Grill Handle
D. 1Touch™ Button
E. Plastic Feet (2) (Not Shown)

THIS PRODUCT IS EQUIPPED WITH A POLARIZED AC (Alternating Current)PLUG (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet.

DO NOT DEFEAT THE SAFETY PURPOSE OF THIS POLARIZED PLUG IN ANY WAY.

ASSEMBLY INSTRUCTIONS

Step 1: Carefully unpack all the contents of this carton. For the HABF27: Take the two plastic feet and insert each into the two holes located on the bottom of the fan. Push the bottom of the plastic feet until they snap into the two holes.

OPERATING INSTRUCTIONS

Your fan is equipped with the technologically advanced "1Touch™ " Accutemp thermostat. This feature will automatically turn the fan "ON" or "OFF" depending on the preset comfort level. The comfort level ranges between 60° and 80°F.

- Plug the fan into a 120V AC electrical outlet
- To start the unit and run continuously, push the button once for the High setting and press the button twice for the Low setting
- To stop the unit, press and hold the button for two seconds or keep pressing the button until all the speed and temperature indicators are off.

One Touch Thermostat Instructions

To take advantage of the 1Touch™ Thermostat, continue to press the button until the desired temperature is reached. When ambient temperature drops below the set temperature, the fan will stop. When the outside temperature rises above the set point, the fan will turn on automatically.

Air Flow Direction

To change the direction of the air flow, move the directional grill to the desired location.

CLEANING / MAINTENANCE

Follow these instructions to correctly and safely care for your 1Touch™ Box Fan. Please remember:

- Always unplug the fan before cleaning or disassembling.
- Do not allow water to drip on or into the fan motor housing.
- Do not use any of the following as a cleaner: gasoline, thinner, benzine.

Fan Blade Cleaning

Step 1: To access the fan blade, remove the six screws from the Rear Grill. Clean the fan blade, both front and rear grills with a soft cloth moistened with a mild soap solution. Do not immerse the motor in water. Also, do not operate the fan with grill(s) removed.

Note: Please be cautious around the motor housing area. Do not allow the motor or electronics to be exposed to water.

FAN STORAGE

Your fan can be stored in the off-season either partially disassembled or assembled. It is important to keep it in a safe, dry location.

- If stored disassembled, we recommend using the original (or appropriately sized) box.
- If stored assembled or partially assembled, remember to protect the fan head from dust.

SERVICE INSTRUCTIONS

1. Do NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the warranty.
2. If you need to exchange the unit, please return it in its original carton, with a sales receipt, to the store you purchased it. If you are returning the unit more than 30 days after the date of purchase, please see the enclosed warranty.
3. If you have any other questions or comments, see our correspondence below:

The Holmes Group, Inc.
P.O. Box 769
Milford, MA 01757-0769

For your own records, staple or attach your sales receipt to this manual. Also, please take a moment to write the store name/location and date purchased below.

STORE NAME:

LOCATION:

DATE PURCHASED:

(STAPLE RECEIPT HERE)

ONE (1) YEAR LIMITED WARRANTY

SAVE THIS WARRANTY INFORMATION

A. The quality controls used in the manufacture of this Holmes product are to ensure your satisfaction.

B. The Warranty Registration Card enclosed with this product must be completed and returned within 10 days of purchase for your Warranty to be effective. This Warranty applies only to the original purchaser of this product.

C. This Warranty applies ONLY to repair or replacement of any supplied or manufactured parts of this product that, upon inspection by Holmes authorized personnel, proves to have failed in normal use due to defects in material or workmanship. Holmes will determine whether to repair or replace the unit. This Warranty does not apply to installation expenses.

D. Operating this unit under conditions other than those recommended or at voltages other than the voltage indicated on the unit, or attempting to service or modify the unit, will render this WARRANTY VOID.

E. Unless otherwise proscribed by law, Holmes shall not be liable for any personal injury, property or any incidental or consequential damages of any kind (including water damage) resulting from malfunctions, defects, misuse, improper installation or alteration of this product.

F. All parts of this Holmes product are guaranteed for a period of 1 year as follows:

1. Within the first 30 days from date of purchase, the store from which you purchased your Holmes product should replace this product if it is defective in material or workmanship (provided the store has in-stock replacement.)
2. Within the first twelve months from date of purchase, subject to the conditions in paragraph H, Holmes will repair or replace the product if it is defective in material or workmanship providing it is returned to Holmes, freight prepaid, with PROOF OF PURCHASE date, together with $5.00 for handling and return packing/shipping charges.

G. If you have any problem with this product, please write or call our Consumer Service Department.

H. IMPORTANT Return INSTRUCTIONS Your warranty depends on your following these instructions if you are returning the unit more than 30 days after the date of purchase:

1. Carefully pack the item in its original carton or other suitable box to avoid damage in shipping.
2. Before packing your unit for return; be sure to enclose:

   a) your name, full address with zip code and telephone number,

   b) a dated sales receipt or PROOF OF PURCHASE,

   c) your $5.00 check for return packaging, and

   d) The model number of the unit and the problem you are having. (Enclose in an envelope and tape directly to the unit before the box is sealed.)
3. Holmes recommends you insure the package (as damage in shipment is not covered by your warranty).
4. All shipping charges must be prepaid by you (as noted in paragraph F).
5. Mark the outside of your package:

THE HOLMES GROUP, INC.
CONSUMER RETURNS
2 PULLMAN ST
WORCESTER, MA 01606

SHIPPING AND HANDLING CHARGES: $5.00

This warranty gives you specific legal rights, and you may have other rights which vary from state to state. The provisions of this warranty are in addition to, and not a modification of, or subtraction from, the statutory warranties and other rights and remedies contained in any applicable legislation. To the extent that any provision of this warranty is inconsistent with any applicable law, such provision shall be deemed voided or amended, as necessary, to comply with such law.